

Specifications for card printing

- Cards are printed on the front (e. g. English) and back (foreign languages, e. g. German, Turkish, Russian, Arabic).
- Use cardboard of approximately 250 g so that the back of the card does not show through when backlit.
- The cards are cut to fit a standard DIN A4 laminating film (approx. 125 microns) and the top edge is trimmed by 2 cm. The size of the cardboard will then be approximately 190mm x 290mm. When laminating, this will result in an edge of laminating film approximately 20mm wide with no cardboard in between, see illustration below.
- On the top edge (landscape format, 20 mm laminate edge), 2 holes are punched in the centre, 80 mm apart, for attaching the ball chains.
- The perforation should only go through the laminated film and not through the laminated cardboard. Otherwise, the disinfectant solution could seep into the cardboard and damage it.
- To hang the cards, use a 25cm ball chain with a split ring.
- Example

